



POWERHEAD PLUG RETROFIT KIT

INSTALLATION INSTRUCTIONS:

(Installation Time: 1/2 hour)

TOOLS REQUIRED: Philips Head Screwdriver, 5/16" wrench

1. Disassemble machine and install kit as shown.
2. Connect wires as shown in wiring diagram.

KIT CONTENTS

P/N.	Description	Qty.
603401	Pigtail, PowerHead	1
603813	Spacer, Black	1
603814	Retainer	1

