KIT NO. 604359 Page 1 of 1



PUMP RETROFIT KIT

INSTALLATION INSTRUCTIONS:

TOOLs REQUIRED: Utility Knife, 3/16" Allen Wrench, 5/16", 7/16" & 9/16" Wrench. (Installation Time: 1 hour)

