



INSTALLING AND REMOVING THE SCRUB BRUSHES

FOR SAFETY: Before installing brushes, park machine on level surface, turn off machine and remove key.

- A. For easy brush installation, set the yellow spring clip to the open position by pressing clips together and downward.



- B. Align the brush under the motor hub and push it upward to engage hub. Make sure brushes are securely engaged.



- C. To remove the brushes, raise scrub head and step on the yellow brush release plunger.



- D. Replace brushes when the brush bristles are worn to the yellow indicator.

