
ATTENTION

To prevent dust skirt damage, TILT machine back when removing from shipping pallet.



You MUST Remove Wire-tie Before Operating Machine.

