



INSTRUCTION BULLETIN

No. 1020

Machines: All models
with fire extinguisher
as an accessory.

Published: 9-87

Installation Instructions for Fire Extinguisher 25312.

For some machines, there are different kit numbers, but they all contain the same fire extinguisher 25312, mounting bracket, and hardware.

Kit 46938 is used on Models 220, 42, 42E, 42HD, 86, 86E, 90, 91, 53, 92, 760, 520, 2R, L-2, 250, 280, 186, 186E, 255, 275, 360, 365, and 100.

Kit 50615 is for the Model 95.

Kit 69772 is for the 527 Series.

Kit 86149 is for the 530E.

Kit 78127 is for the 550, 550E.

PROCEDURE:

1. Park the machine on a level surface. Turn off the engine or motor and set the parking brake (if applicable) before working on the machine.

WARNING: Always stop the machine and set the parking brake before working on the machine.

2. Refer to the attached photographs or drawings to show recommended mounting location on your machine.
3. Use the mounting bracket as a template to mark location of mounting holes. Drill 7/32" diameter holes.
4. Install bracket.
5. Mount fire extinguisher.

TENNANT COMPANY
P. O. Box 1452
Minneapolis, MN 55440-1452
(612)540-1200

Models 186 & 186E




Fig. 11 - Fire Extinguisher Kit

02597

Key	Tennant® Part No.	Machine Serial Number	Description	Qty.
1	46938 25312	(000000- (000000-) Extinguisher Kit, Fire) Extinguisher, Fire	1 1

The fire extinguisher is placed on the left vertical panel beneath the labels, as viewed by the operator.

Model 95




FIG. 20 - FIRE EXTINGUISHER KIT

01578

KEY	TENNANT® PART NO.	MACHINE SERIAL NUMBER	DESCRIPTION	QTY.
1	50615 25312	(- (-) FIRE EXTINGUISHING KIT) EXTINGUISHER, Fire	1 1

Models 255 & 275:




Fig. 38 - Fire Extinguisher Kit

02597

Key	Tennant® Part No.	Machine Serial Number	Description	Qty.
1	46938	(000000-)	Extinguisher Kit, Fire	1
	25312	(000000-)	Extinguisher, Fire	1

Model 255, 275, with cab:

Mount extinguisher on rear upright at door side of cab.

Models 360 & 365:




Fig. 9 - Fire Extinguisher Kit

02300

Key	Tennant® Part No.	Machine Serial Number	Description	Qty.
1	46938	(000000-)	Extinguisher Kit, Fire	1
	25312	(000000-)	Extinguisher, Fire	1

Model 360, 365 with cab:

Mount the fire extinguisher inside the cab above the fuel level gauge, battery condition gauge, and the operating lamps switch.

527 Series:




FIG. 11 - FIRE EXTINGUISHER KIT

00532

KEY	TENNANT® PART NO.	MACHINE SERIAL NUMBER	DESCRIPTION	QTY.
1	69772	(0000S24000-) FIRE EXTINGUISHER KIT	1
	25312	(0000S24000-) EXTINGUISHER, Fire	1

Model 530E:




Fig. 12 - Fire Extinguisher Kit

03433

Key	Tennant® Part No.	Machine Serial Number	Description	Qty.
	86149	(000000-) Extinguisher Kit, Fire	1
1	86621	(000000-) Bracket, Fire Extinguisher	1
2	25312	(000000-) Extinguisher, Fire	1

Mount the extinguisher in the operator's compartment at the left.

Models 550 & 550E




FIG. 23 - FIRE EXTINGUISHER KIT

00830

KEY	TENNANT® PART NO.	MACHINE SERIAL NUMBER	DESCRIPTION	QTY.
1	78127	(0000002183-0000003369)	EXTINGUISHER KIT, Fire	1
	25312	(0000002183-0000003369)	EXTINGUISHER, Fire	1

Model 250




FIG. 10 - FIRE EXTINGUISHER KIT

00713

KEY	TENNANT® PART NO.	MACHINE SERIAL NUMBER	DESCRIPTION	QTY.
1	46938	(-)	EXTINGUISHER KIT, Fire	1
	25312	(-)	EXTINGUISHER, Fire	1

Model 250, with cab:

Mount the extinguisher on the rear left vertical leg of the cab on the radiator side.

Model 280:






FIG. 24 - FIRE EXTINGUISHER KIT

00713


KEY	TENNANT® PART NO.	MACHINE SERIAL NUMBER	DESCRIPTION	QTY.
1	46938	(-)	EXTINGUISHER KIT, Fire	1
	25312	(-)	EXTINGUISHER, Fire	1




FIRE EXTINGUISHER BRACKET




220



42 - 42E - 42HD




86 - 90 - 91




53


IB1020(9-87)LITHO IN U.S.A.




92




86E




760




520



2R



L2



100

