

SCOUT 3/3B/5/9 | WALK-BEHIND SWEEPERS

GENUINE PARTS & CONSUMABLES



BRUSHES

PRODUCT DESCRIPTION	Scout 3 PART #	Scout 3B PART #	Scout 5 PART #	Scout 9 PART #
Main Brush, Nylon, 20 in (500mm) 2 req'd/machine	9009995		-	9010036
Main Brush, Nylon, 16 in (400mm) 2 req'd/machine	-	-	9010035	-
Side Brush, Nylon, 7.8 in (200 mm) 2 req'd/machine	9009997		-	9010040
Side Brush, Nylon, 6.7 in (170 mm)	-	-	9010039	-

FILTER

PRODUCT DESCRIPTION	Scout 3 PART #	Scout 3B PART #	Scout 5 PART #	Scout 9 PART #
Dust Filter	-	9009998	9010041	9010042

BATTERY

PRODUCT DESCRIPTION	Scout 3 PART #	Scout 3B PART #	Scout 5 PART #	Scout 9 PART #
Battery, 12V, 26 AH	-	1068827	-	-
Battery, 12V, 50 AH	-	-	1065086	-
Battery, 12V, 105 AH	-	-	-	1071125

WEAR & REPAIR PARTS

PRODUCT DESCRIPTION	Scout 3 PART #	Scout 3B PART #	Scout 5 PART #	Scout 9 PART #
Swivel Caster Kit	9010021		9010058	9010059
Wheel Kit, 2 req'd/machine	9010018		9010054	9010055
Main Brush Chain [3 & 3B] / Belt Kit [5 & 9]	9010022		9010077	9010078
Side Brush Belt Kit, 2 req'd/machine	9010025		-	-
Side Brush Pullet Kit, 2 req'd/machine	9010121		-	-

For prices or to order, call Tennant Customer Service at 1-800-553-8033 or order online at www.tennantweblink.com.
Prices and programs subject to change without notice.