



SOUND REDUCTION KIT

INSTALLATION INSTRUCTIONS:

(Installation Time: 30 min.)

TOOLS REQUIRED: 7/16" Wrench, Philips Screwdriver.

FOR SAFETY: Before installing kit, disconnect battery connections or unplug power cord from wall outlet.

1. Hinge open battery compartment and remove vacuum motor from recovery tank.
2. Reinstall vacuum motor using kit contents as shown.

#606671 KIT CONTENTS

P/N	Description	Qty
606514	Motor Mount	3
606515	Standoff	3
140889	Screw, 1/4-20x3/4	3
606516	Gasket, Vacuum Motor	1
606669	Muffler, Vacuum Motor	1
130041	Wire Tie	1
140052	Washer, External Tooth Lock	3

