
No. 264 - North America

Release Date: April 9, 2021

Technical Service Bulletin



TENNAN

plugged into the charger and secured to the main wire harness and that there is adequate slack in the charger cable when the seat is lifted open. There should not be any pull on the on-board battery charger cable and the main wire harness when the seat is lifted open. (Fig. 2)

Questions, contact the Tennant Customer Service Department at (800) 553-8033.

Warranty Information: Standard warranty terms apply.



Termination points for the static ground wire. Refer to IB 9045099 included with kit 9045098 for installation/routing instructions.

FIG. 1

Photographs applicable to machines equipped with on-board battery charger option only



Ensure on-board charger cable is completely plugged into on-board charger.



Ensure on-board charger cable is secured to seat channel and main wire harness.



Ensure on-board charger cable is secured to main wire harness.



Ensure there is adequate slack in on-board charger cable so cable is not damaged when seat is lifted open.

FIG. 2