









24V TRANSAXLE REPLACEMENT KIT

INSTALLATION INSTRUCTIONS:

(Installation Time: 1.5 hours)

TOOLS REQUIRED: 7/16", 9/16" & 17mm Socket Wrench & Wire—Tie Cutters.

BEFORE INSTALLING KIT: Drain all water from machine, remove batteries and with adequate assistance carefully turn machine upside down to access the drive transaxle.

FOR SAFETY: When servicing machine, wear protective gloves when handling batteries or battery cables. Avoid contact with battery acid.

KIT CONTENTS		
P/N.	Description	Qty.
1013312	TRANSAXLE, 24V MOTOR, 116 RPM	1 1
612908	WIRE, ADAPTER, TRANSAXLE	1
140501	NUT, NL 1/4-20 SS	8
130040	TIE, WIRE 6"X.12 NY	2
606001	BRACKET, TRANSAXLE MNTG (A)	1
612784	BRACKET, TRNSAXL MNTG (B)	1
630127	BRACKET, TRANSAXLE MNTG (C)	1
612255000	SCREW M10X1.5X35 HX	1
A	B C	

NOTE: Existing Mounting Hardware is required with Kit. Use soapy water to install mount brackets on transaxle.

